

► USER GUIDE



SYMKLOUD System Monitor v3.0

Doc. Rev. 1.0

► SYMKLOUD SYSTEM MONITOR V3.0 - USER GUIDE

Disclaimer

Kontron would like to point out that the information contained in this manual may be subject to alteration, particularly as a result of the constant upgrading of Kontron products. This document does not entail any guarantee on the part of Kontron with respect to technical processes described in the manual or any product characteristics set out in the manual. Kontron assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright or mask work rights to these products and makes no representations or warranties that these products are free from patent, copyright or mask work right infringement unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Kontron makes no representation or warranty that such application will be suitable for the specified use without further testing or modification. Kontron expressly informs the user that this manual only contains a general description of processes and instructions which may not be applicable in every individual case. In cases of doubt, please contact Kontron.

This manual is protected by copyright. All rights are reserved by Kontron. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), without the express written permission of Kontron. Kontron points out that the information contained in this manual is constantly being updated in line with the technical alterations and improvements made by Kontron to the products and thus this manual only reflects the technical status of the products by Kontron at the time of publishing.

Brand and product names are trademarks or registered trademarks of their respective owners.

© 2013, 2014 by Kontron America, ©2016 by Kontron AG

Kontron Ag

Lise-Meitner-Str. 3-5
86156 Augsburg
Germany
www.kontron.com

Revision History

Revision	Brief Description of Changes	Date of Issue
1.0	SYSTEM MONITOR V3.0 initial release	September 2016

Customer Support

Find Kontron contacts at <http://www.kontron.com/support>.

Customer Service

As a trusted technology innovator and global solutions provider, Kontron extends its embedded market strengths to a services portfolio that allows companies to break the barriers of traditional product lifecycles. Proven product expertise coupled with collaborative and highly-experienced support enables Kontron to provide exceptional peace-of-mind for the building and maintenance of successful products.

For more details on Kontron's service offerings, including enhanced repair services, extended warranty, the Kontron training academy visit <http://www.kontron.com/support-and-services/services>.

Customer Comments

If you have any difficulty using this guide, find an error or wish to provide feedback, please contact [Kontron Support](#). Please provide details of any errors you may find. We will correct these errors or problems as soon as possible and post the revised user guide on our website.

Thank you.

Table of Contents

Table of Contents	4
List of Figures	5
List of Acronyms.....	6
1/ About this manual.....	7
1.1. About System Monitor	7
1.2. About the SYMKLOUD platform.....	7
2/ Getting started with the System Monitor	8
2.1. Connecting to the application	8
2.2. Login.....	8
3/ System Monitor dashboard	9
3.1. Power consumption graph.....	9
3.2. Console Access.....	9
4/ About the menus	11
5/ Monitor.....	12
5.1. Detailed component view.....	13
5.1.1. Board information.....	14
5.1.2. Fan speeds	14
5.1.3. General information.....	14
5.1.4. Network interfaces	16
5.1.5. Platform graphical representation	16
5.1.6. Power commands.....	17
5.1.7. Power consumption graph	18
5.1.8. Remote access.....	18
5.1.9. Remote access password.....	18
5.1.10. Reset peak/average.....	18
5.1.11. Sensor values.....	18
5.1.12. Servers.....	19
5.1.13. Software versions.....	19
5.1.14. Switch	20
5.1.15. Switch speed (HubNode model MSH8900).....	20
5.1.16. Tools.....	20
5.2. Platform information	21
5.3. HubNode information.....	22
5.4. Node information	22
5.5. Switch details.....	23
5.6. Server details: MSP8000 and MSP8001.....	24
5.7. Server details: MSP8020	25
5.7.1. Network interfaces.....	26
5.8. PSU details.....	27
6/ WEB CLI	29
6.1. Connecting to the WEB CLI.....	29
6.2. Login	29
7/ System Event Log (SEL).....	30
7.1. Viewing the SEL.....	30
7.2. Exporting the events to a CSV file	31
8/ OneClick upgrade.....	32
8.1. Upgrade sequence.....	32

8.2. Advanced settings	32
8.3. Bundle settings	33
8.4. Launching an upgrade	33
8.5. Upgrade status.....	33
8.5.1. Platform level.....	34
8.5.2. Component level	34
9/ Remote access	35
10/ Network configuration.....	36
10.1. System monitor shared IP	36
10.2. IPMI Over LAN configuration.....	36
11/ Settings.....	38
11.1. Tech view	38
11.2. Admin view	38
11.2.1. Change password.....	40
11.2.2. Interface preferences.....	40
11.2.3. User management	41
11.2.4. Security	43
11.2.5. Certificate and private key	43
11.2.6. Strict SSL Validation and CA Certificate.....	43
12/ Help	44
12.1. API documentation.....	44
12.2. About.....	44

List of Figures

Figure 1: Power consumption graph.....	9
Figure 2: Console Access drop-down box.....	10
Figure 3: Features.....	11
Figure 4: Help menu.....	11
Figure 5: Profile menu	11
Figure 6: Monitor view	12
Figure 7: Component list filter.....	12
Figure 8: Component list filtered by hardware type	13
Figure 9: Component and platform level warnings.....	13
Figure 10: Board information	14
Figure 11: Fans speeds.....	14
Figure 12: General information.....	15
Figure 13: General information.....	15
Figure 14: Platform graphical representation.....	17
Figure 15: Platform graphical representation component page.....	17
Figure 16: Power commands.....	17
Figure 17: Sensor values.....	19
Figure 18: Servers	19
Figure 19: Software versions	20
Figure 20: Switch	20
Figure 21: Switch speed for HubNode model MSH8900.....	20
Figure 22: Tools.....	21
Figure 23: Platform information.....	21
Figure 24: HubNode information.....	22
Figure 25: Node information	23
Figure 26: Switch details.....	24
Figure 27: Server details (MSP8000 and MSP8001).....	25
Figure 28: Server details MSP8020.....	26
Figure 29: Network interfaces.....	26

Figure 30: PSU details	28
Figure 31: System event log	30
Figure 32: OneClick upgrade	32
Figure 33: Advanced settings	32
Figure 34: Change bundle	33
Figure 35: Start upgrade.....	33
Figure 36: Upgrade status	34
Figure 37: Remote access	35
Figure 38: Network configuration.....	36
Figure 39: General settings for a technician.....	38
Figure 40: General settings for an administrator.....	39
Figure 41: Change password.....	40
Figure 42: Interface preferences.....	41
Figure 43: User management.....	42
Figure 44: Creating new user	42
Figure 45: Error message: user already exists.....	43
Figure 46: Security	43
Figure 47: API documentation example	44
Figure 48: About window.....	44

List of Acronyms

API	Application Programming Interface
BMC	Base Management Controller
CLI	Command-Line Interface
IOL	IPMI-Over-LAN
IPMI	Intelligent Platform Management Interface
HubNode	A switching and platform management node
KVM	Keyboard Video Mouse
SEL	System Event Log
ShMC	Shelf Management Controller
SOL	Serial Over LAN

1/ About this manual

This document describes current features of the System Monitor web application. It provides a complete description and usage of this web application.

1.1. About System Monitor

The SYMKLOUD Shelf Manager host a monitoring, management and maintenance application called System Manager. The functions of the System Manager are available through an API or a web interface. The System Monitor is the web interface also hosted by the Shelf Manager. It provides a graphical representation of the features given by System Manager's API. This manual explains how to use the System Monitor web application.

Refer to the System Manager Programmer's Guide for more information on the API.

1.2. About the SYMKLOUD platform

The Kontron SYMKLOUD Series are massively scalable SDN/NFV-enabled converged modular platforms for carrier, cable, and cloud infrastructure deployments. Achieve highly efficient application workloads for Video/Content Delivery, Big Data/IoT, Mobile/Telco, and Cloud/Hosting services. It has the following characteristics:

- ▶ Designed from the ground up to integrate switching, load balancing and processing in a 3-in-1 modular approach
- ▶ Power efficiency for significant OPEX savings
- ▶ Simplified One-Click updates
- ▶ Seamless clustering and rack scalability
- ▶ Designed for cloud service providers and next-generation data centers

The SYMKLOUD platform is composed of two HubNodes to provide hardware redundancy. In this model, one HubNode is "Active" and the other is "Standby" with role switchover if a problem occurs on the "Active" Shelf Manager.

2/ Getting started with the System Monitor

2.1. Connecting to the application

Each SYMKLOUD's HubNode runs an instance of the web application. To connect to the application, it is recommended to use the latest version of Chrome. It is also strongly recommended to configure and to connect to the "Shared IP" feature as described in the System Manager Programmer's Guide. The "Shared IP" will always give access to the "Active" Shelf Manager.

The application refreshes its information every 5 seconds. Because of this, any change to a state or value of a physical component of the actual platform can take up to 5 seconds before being reflected in the web application (e.g., fan speeds, hotswap status, alarms or power consumption values).

Enter the management IP (or "Shared IP", if configured) of the "Active" Shelf Manager in the browser address bar to open the System Monitor in your favorite browser. Connecting to the IP address of the "Standby" Shelf Manager will display a message that the application can be used only on the "Active" Shelf Manager. This message will provide a direct link to the "Active" Shelf Manager.

2.2. Login

The System Manager provides role-based user access for its API. The web application uses the same credentials to manage its access. At first login, use the following default credentials to access the application:

- ▶ Username : admin
- ▶ Password: admin

NOTICE

The admin password must be changed at first login. Refer to 11.2 Admin view for how to modify the admin password.

Once logged in, users can modify their password. Any user with the "Admin" role can access the "General Settings" page "User Management" section to create, delete or modify users for the platform. The API uses the same access credentials as the web interface.

3/ System Monitor dashboard


After login, the "Dashboard" page will be displayed, which provides:

- ▶ links to the main sections of the application
- ▶ a graph of the power consumption of the platform(s) in the last hour
- ▶ access to the CLI of the HubNodes

3.1. Power consumption graph

The graph data is gathered and displayed in the browser as soon as a user logs in. This data is only kept in the browser session. Logging out will remove all accumulated data from memory.

Figure 1: Power consumption graph



3.2. Console Access

Use the "Console Access" drop-down box to select a HubNode to connect to using the web console. Once a HubNode is selected, the frame below the selection box will connect to the HubNode via the remote web shell and a login-prompt will be displayed. There are two possible users available for login, and each will present a different CLI. Refer to Chapter 6/ WEB CLI for more details on the login options.

NOTICE

The WEB CLI can also be used to access this interface in a dedicated window, without logging into the WebUI. Refer to Chapter 6/ WEB CLI for more details.

Figure 2: Console Access drop-down box

The screenshot displays the SYMKLOUD System Monitor v3.0 interface. At the top, there is a navigation bar with the SYMKLOUD logo, a search icon, and user profile icons. Below the navigation bar is a dashboard section with several cards:

- Dashboard**: Includes links to Monitor, System Event Log, OneClick Upgrade, Remote Access, and Network Configuration.
- Tools**: Includes a link to OneClick Upgrade.
- Multi-Platform**: Shows a card for Platform #1 with a green checkmark.

On the right side of the dashboard, there is a graph titled "Power Consumption Graph / Last hour". The graph shows power consumption in Watts over time, with a prominent horizontal line at approximately 80W and several spikes reaching up to 100W. A legend indicates "Platform #1".

At the bottom right of the dashboard area, there is a "Console Access" section with a dropdown menu:

Please select a platform


- Platform #1 HubNode 1
- Platform #1 HubNode 2

4/ About the menus

Features

The top of the System Monitor application contains a "Hamburger Menu" that provides quick access to the application's main features. This menu is available on all pages.

Figure 3: Features



Help

The Help menu provides a link to API documentation and a link to the version information of both the web application and the application running on the HubNode. The API documentation will open in another tab. "About" will load a pop-up box with version information.

Figure 4: Help menu



Profile

The Profile menu provides "Settings" and "Logout" options. For more information about settings, refer to 11/ Settings.

Figure 5: Profile menu




5/ Monitor

Monitor view provides a physical representation of the platform and a list of its components. The darker portion of the visual shows the front of the SYMKLOUD, which houses the two HubNodes. The lighter portion of the visual shows the back of the SYMKLOUD, where the nodes, PSUs and (optional) uplink modules are found. Clicking on a component or sub-component name on the platform's visual representation or on the component list will open its detailed component view.

Figure 6: Monitor view

[Dashboard](#) > [Monitor](#)

Components



Component list

The left side of this section provides an expandable list of all the components contained in each platform. Use the filter at the top of the list so that only specific items can be seen, either by "Hardware Type" or by "Model."

Figure 7: Component list filter




Figure 8: Component list filtered by hardware type

The screenshot shows a 'Multi-Platform' interface. At the top, a dropdown menu is set to 'HubNode'. Below it, a section titled 'Platform #1' is expanded, showing two entries: 'HubNode 1' and 'HubNode 2'. Each entry includes a small icon, the component name, its model ('MSH8900'), and its IP address ('192.168.101.1' and '192.168.101.2' respectively). To the right of each entry is a circular status indicator: a green circle with a white checkmark for 'HubNode 1' and a yellow circle with an exclamation mark for 'HubNode 2'.

Alarm indication

A green circle with a white check next to a platform (see above) indicates no alarm.

A yellow warning symbol next to a component and a platform indicates an alarm is detected. The severity of the alarm is not indicated in the web application, but can be obtained with the "Platform System Information" file (Refer to 5.1.16 Tools).

Figure 9: Component and platform level warnings

The screenshot shows a 'Multi-Platform' interface. A dropdown menu at the top is set to 'MSP8020'. Below it, a section titled 'Platform #0' is expanded, showing five entries: 'Node 1', 'Node 5', 'Node 6', 'Node 8', and 'Node 9'. Each entry includes a small icon, the component name ('Node'), its model ('MSP8020'), and its IP address ('192.168.0.1', '192.168.0.5', '192.168.0.6', '192.168.0.8', and '192.168.0.9' respectively). To the right of each entry is a yellow circular status indicator with an exclamation mark, indicating a warning for all components in this platform.

5.1. Detailed component view

The detailed component view displays sections available for each component type. The following describes all the sections available and specifies for which components they are available.

5.1.1. Board information

This section is present for:

- ▶ HubNode information
- ▶ Node information

The board information section displays detailed information, such as product part number and serial number.

Figure 10: Board information

Board Information	
mfgDate:	Wed Oct 23 18:44:00 2013
boardMfg:	Kontron
boardProductName:	4003
boardProductPart:	T4003BB_1-DGGXX
boardSerialNumber:	9013051155


5.1.2. Fan speeds

This section is present for:

- ▶ Platform information

The fan speeds section displays animated radial gauges that indicate the speed of each platform fan.

Figure 11: Fans speeds



5.1.3. General information

This section is present for:

- ▶ Platform information
- ▶ HubNode information
- ▶ Node information
- ▶ Switch details
- ▶ Server details
- ▶ PSU details

For platform information:

Figure 12: General information

General Information

Name:	Platform #1
Platform Number:	1
Health:	

Parameter	Description
Name	Composed with the "Platform Number".
Platform number	The stacking number associated with the platform.
Health	If a platform component has an alarm, it will display a warning symbol .

For all other components:

Figure 13: General information

General Information

Name:	HubNode 2
API Node number:	11
Model:	MSH8900
Board Status:	Active, M4
Management IP:	192.168.101.2
Health:	
HA Status:	Standby

Parameter	Description
Name	A unique name for the component in the platform. This parameter applies to: <ul style="list-style-type: none">▶ HubNode information▶ Node information▶ Switch details▶ Servers details PSU details: This is the type name only since this interface contains information for both PSUs.
API Node number	Used in API calls to target this node. (HubNodes are node resources in the API). This parameter applies to: <ul style="list-style-type: none">▶ HubNode information▶ Node information
Model	The name of the board model.

Parameter	Description
	<p>This parameter only applies to:</p> <ul style="list-style-type: none"> ▶ HubNode information ▶ Node information
Board status	<p>Hotswap status of the board (one of the following):</p> <ul style="list-style-type: none"> ▶ Inactive, M1: The board is powered OFF ▶ Activating, M2: Activation request sent ▶ Activating, M3: Activation in progress ▶ Active, M4: The board is powered ON ▶ Deactivating, M5: Deactivation request sent ▶ Deactivating, M6: Deactivation in progress ▶ Communication lost, M7: The shelf manager cannot communicate with the board <p>This parameter only applies to:</p> <ul style="list-style-type: none"> ▶ HubNode information ▶ Node information ▶ Switch details ▶ Servers details
Management IP	<p>IP Address of the management interface of this component (used for IPMI Over LAN (IOL))</p> <p>This parameter only applies to:</p> <ul style="list-style-type: none"> ▶ HubNode information ▶ Node information
Health	<p>Green if there are no alarms or yellow if there are alarms. The details of the sensors can be found in the Platform System Information file (Refer to 5.1.16 Tools).</p> <p>In addition to platform information, this parameter applies to:</p> <ul style="list-style-type: none"> ▶ HubNode information ▶ Node information
HA status	<p>HubNodes run in active/standby mode for redundant high availability. This field indicates if the current HubNode is active or standby.</p> <p>This parameter only applies to HubNode information.</p>

5.1.4. Network interfaces

This section is present for:

- ▶ Switch details
- ▶ Server details

This allows the user to manually store an IP address associated with this sub-component. Once associated, clicking on the "Configuration Page" button will open another browser tab to the corresponding IP address.

5.1.5. Platform graphical representation

This section is present for all components.

Figure 14: Platform graphical representation




This is the graphical representation of the platform. The black background offset section on the top represents the front of a SYMKLOUD where the two HubNodes are located. The rectangle at the bottom with the gray background represents the back of a SYMKLOUD where the nodes and the PSUs are located. As shown in the example above, each HubNode and node component also displays its model next to its name, showing the location of each type of node. Name and model information is also a link to the detailed view of that specific component.

A yellow warning symbol next to a component indicates that an alarm is detected.

When in a component or sub-component detail page, the platform representation displays a different background color for the physical location of the selected component or sub-component.

Figure 15: Platform graphical representation component page



5.1.6. Power commands

This section is present for:

- ▶ Node information
- ▶ Switch details
- ▶ Server details

Components	Available commands
Node information	At the node level, power commands will affect the board and sub-components. Available commands may change depending on board model.
Switch details	Only the "Reset" command is available for a switch.
Server details	"Activate", "Deactivate" and "Reset" commands are available for this model.

Figure 16: Power commands

Power Commands

Command will be executed on baseboard and all servers it contains

ACTIVATE
DEACTIVATE
RESET

5.1.7. Power consumption graph

This section is present for:

- ▶ PSU details

Each PSU has its own data plot on this graph. The values come from the same data as the dashboard graph and are lost when logging out.

5.1.8. Remote access

This section is present for:

- ▶ Server details

NOTICE

This section may not be present for all server models

A Java KVM/VM (keyboard video mouse/virtual media) is available on some board models. Clicking on the "Remote Access" button will open a new tab to launch Java applet for remote access to this board.

NOTICE

At the first launch, the Java version may require that the BMC IP be added to a security whitelist to allow execution of the Applet.

5.1.9. Remote access password

This section is present for:

- ▶ Server details

NOTICE

This section may not be present for all server models

Set the password for KVM access to this server. Requirements for the password are:

- ▶ Exactly 8 characters long
- ▶ At least 1 upper case letter
- ▶ At least 1 lower case letter
- ▶ At least 1 number
- ▶ At least 1 symbol

Saving alone will not apply the password to the remote server; the CPU/server must also be provisioned and remote access used at least once. Once provisioned, this password will be required to connect remotely to the server.

5.1.10. Reset peak/average

This section is present for:

- ▶ PSU details

Clicking on the "reset peak/average" button resets the values of the average and peak consumption data to zero.

5.1.11. Sensor values

This section is present for:

- ▶ PSU details

Figure 17: Sensor values

Power Supply 1		Power Supply 2	
Inlet Temperature:	22 °C	Inlet Temperature:	22 °C
Outlet Temperature:	28 °C	Outlet Temperature:	25 °C
Input Voltage:	118 Volts	Input Voltage:	118 Volts
Power Out:	32 Watts	Power Out:	56 Watts
Peak Consumption:	144 Watts	Peak Consumption:	88 Watts
Average Consumption:	55 Watts	Average Consumption:	77 Watts

This section displays the temperature and power consumption information for a given PSU. The following information will be displayed:

- ▶ Inlet temperature
- ▶ Outlet temperature
- ▶ Input voltage
- ▶ Power out
- ▶ Peak consumption
- ▶ Average consumption

Temperature, voltage and power out readings are instantaneous readings.

Peak and average consumption values are calculated and stored in the browser as long the user stays loged in. A maximum of one hour of data will be kept.

The peak and average consumption can be manually reset using the "Reset Peak/Average" button.

5.1.12. Servers

This section is present for:

- ▶ Node information

This section provides links to the detail pages of the individual servers. Depending on the model of the board, more than one server may be accessible on a node.

Figure 18: Servers

Servers
<ul style="list-style-type: none"> ■ Server 1 0.0.0.0 ■ Server 2 0.0.0.0

5.1.13. Software versions

This section is present for:

- ▶ HubNode information
- ▶ Node information

Versions of the main board components: BMC, FPGA and BIOS.

Figure 19: Software versions

Software Versions	
BMC:	2.18.08FA45E0
FPGA:	2.12.00000000
BIOS:	2.14.00000000

5.1.14. Switch

This section is present for:

- ▶ HubNode information

Link to the page of the Switch sub-component:

Figure 20: Switch

Switch
 Switch 1 0.0.0.0

5.1.15. Switch speed (HubNode model MSH8900)

This section is present for:

- ▶ Platform information

The switches for HubNode model MSH8900 each have 2 ports going to slots 7 and 9: one 1 GB/s port and one 10 GB/s port. Use this view to toggle the physical port speed of the 10 GB/s port between 1 GB/s and 10 GB/s.

If you use the board model MSP8001 or MSP8032 in slot 7 or slot 9, the speed must be set to 10 GB/s.

If you use any other board model in slot 7 or slot 9, the speed must be set to 1 GB/s.

When saving changes to the switch speed, both switches are rebooted to apply the settings. Clicking the "Save Changes" button will display a warning message about the switch reboot and ask for user confirmation to continue.

Figure 21: Switch speed for HubNode model MSH8900


Switch Speed
Upon modifying these settings, you must extract and reinser the two hubs for the settings to take effect.
Slot 7 Speed :
<input type="radio"/> 1 Gb/s <input checked="" type="radio"/> 10 Gb/s
Slot 9 Speed :
<input type="radio"/> 1 Gb/s <input checked="" type="radio"/> 10 Gb/s
SAVE CHANGES

5.1.16. Tools

This section is present for all components.

The tools section provides links to useful information on the platform.

Figure 22: Tools



Platform system information: Downloads a text file containing detailed information about all the components in the platform. It contains, among other information, the details of the alarms that are reported in the web application for the health of the components. This single document gives a complete view of the state of a platform.

Log files bundle: Downloads a file that can be used by Kontron support team to diagnose problems with the solution running on the HubNode.

Upgrade software: Redirects to the "One-Click Upgrade" page of the web application. The « Upgrade Software » link redirects to the "One-Click Upgrade" page. When this link is clicked from a specific component, the advanced settings of the "One-Click Upgrade" page will be automatically adjusted to target only that component.

5.2. Platform information

The figure below shows platform information. It provides the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Fan speeds. Refer to 5.1.2.
- ▶ Switch speed (HubNode model MSH8900). Refer to 5.1.15.
- ▶ Tools. Refer to 5.1.16.

Figure 23: Platform information

The screenshot shows the "Components" section of the SYMKLOUD System Monitor. On the left, there's a "Multi-Platform" tree view under "Platform #1" with the following components listed:

- HubNode 1 (MSH8900, 192.168.101.1)
- HubNode 2 (MSH8900, 192.168.101.2)
- Node 1 (MSP8001, 192.168.101.11)
- Node 2 (MSP8000, 192.168.101.12)
- Node 4 (MSP8000, 192.168.101.14)
- Node 5 (MSP8020, 192.168.101.15)
- PSU

The main area shows two HubNodes: "HubNode 1 : MSH8900" and "HubNode 2 : MSH8900". Below them is a grid of components: "Node 1 : MSP8001", "Node 2 : MSP8000", "Node 4 : MSP8000", "Node 5 : MSP8020", and two empty slots. To the right, there are two "Power Supply" units, one labeled "2" and one labeled "1".

Below the grid, there are two sections: "General Information" and "Fan Speeds".

General Information:

- Name: Platform #1
- Platform Number: 1
- Health: ✓

Fan Speeds:

Fan	Speed (RPM)
Fan 1	3080 RPM
Fan 2	3080 RPM
Fan 3	3080 RPM
Fan 4	3157 RPM
Fan 5	3080 RPM

5.3. HubNode information

The figure below shows HubNode information. It provides the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Board information. Refer to 5.1.1.
- ▶ Software versions. Refer to 5.1.13.
- ▶ Switch. Refer to 5.1.14.
- ▶ Tools. Refer to 5.1.16.

Figure 24: HubNode information

The screenshot displays the SYMKLOUD System Monitor interface. On the left, a sidebar titled 'Multi-Platform' lists components under 'Platform #1'. It includes 'HubNode 1' (MSH8900, 192.168.101.1), 'Switch 1' (0.0.0.0), and several nodes: 'HubNode 2' (MSH8900, 192.168.101.2), 'Node 1' (MSP8001, 192.168.101.11), 'Node 2' (MSP8000, 192.168.101.12), 'Node 4' (MSP8000, 192.168.101.14), and 'Node 5' (MSP8020, 192.168.101.15). A 'PSU' icon is also listed. On the right, two tabs are open: 'HubNode 1 : MSH8900' and 'HubNode 2 : MSH8900'. The 'HubNode 1' tab shows a 5x2 grid of nodes: Node 1 (MSP8001), Node 2 (MSP8000), Node 4 (MSP8000), Node 5 (MSP8020), and two empty slots. The 'HubNode 2' tab shows a similar grid with two empty slots. Below these tabs, there are two sections: 'General Information' and 'Board Information'. The 'General Information' section contains the following details:

Name:	HubNode 1
API Node number:	10
Model:	MSH8900
Board Status:	Active, M4
Management IP:	192.168.101.1
Health:	✓
HA Status:	Active

The 'Board Information' section contains the following details:

mfgDate:	Wed Oct 30 11:54:00 2013
boardMfg:	Kontron
boardProductName:	4301
boardProductPart:	T4301X_2-X
boardSerialNumber:	9013047417

5.4. Node information

The figure below shows node information. It provides the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Board information. Refer to 5.1.1.
- ▶ Software versions. Refer to 5.1.13.
- ▶ Servers. Refer to 5.1.12.
- ▶ Power commands. Refer to 5.1.6.
- ▶ Tools. Refer to 5.1.16.

Figure 25: Node information

Components

The screenshot shows the SYMKLOUD System Monitor interface. On the left, a tree view titled "Multi-Platform" lists components under "Platform #1". It includes "HubNode 1" (IP 192.168.101.1), "HubNode 2" (IP 192.168.101.2), and several nodes (Node 1 to Node 5) and a PSU. A green checkmark icon is present next to some items. On the right, two main sections are displayed: "HubNode 1 : MSH8900" and "HubNode 2 : MSH8900". Each section has a table with rows for Node 1 to Node 5 and a PSU row. The PSU row for HubNode 1 shows "Power Supply 2" and for HubNode 2 shows "Power Supply 1". Below these tables are "General Information" and "Board Information" sections.

HubNode 1 : MSH8900		HubNode 2 : MSH8900	
Node 1 : MSP8001	Node 2 : MSP8000		Power Supply 2
Node 4 : MSP8000	Node 5 : MSP8020		Power Supply 1

General Information

Name: Node 1
API Node number: 1
Model: MSP8001
Board Status: Active, M4
Management IP: 192.168.101.11
Health:

Board Information

mfgDate: Wed Oct 23 18:44:00 2013
boardMfg: Kontron
boardProductName: 4003
boardProductPart: T4003BB_1-DGGXX
boardSerialNumber: 9013051155

5.5. Switch details

The figure below shows switch details and has the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Network interfaces. Refer to 5.1.4.
- ▶ Power commands. Refer to 5.1.6.
- ▶ Tools. Refer to 5.1.16.

Figure 26: Switch details

The screenshot shows the SYMKLOUD System Monitor interface with the following details:

- Multi-Platform** sidebar: Shows "All components" and a tree view of "Platform #1". Under "HubNode 1" (IP: 192.168.101.1), "Switch 1" (IP: 0.0.0.0) is selected.
- HubNode 1 : MSH8900** and **HubNode 2 : MSH8900** sections: Both show five nodes: Node 1 (MSP8001), Node 2 (MSP8000), Node 4 (MSP8000), Node 5 (MSP8020), and an empty slot.
- Power Supply**: Shows two power supplies, labeled 2 and 1.
- General Information** section: Name: Switch 1, Board Status: Active, M4.
- Network Interfaces** section: IP input field set to 0.0.0.0. Buttons: SAVE and CONFIGURATION PAGE.
- Power Commands** section: RESET button.
- Tools** icon in the top right corner.

5.6. Server details: MSP8000 and MSP8001

The figure below shows server details for the MSP8000 and MSP8001. It provides the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Network interfaces. Refer to 5.1.4.
- ▶ Remote access. Refer to 5.1.8.
- ▶ Power commands. Refer to 5.1.6.
- ▶ Tools. Refer to 5.1.16.

Figure 27: Server details (MSP8000 and MSP8001)

Components

The screenshot shows the SYMKLOUD System Monitor interface. On the left, a tree view under "Multi-Platform" shows "All components" and "Platform #1". Under Platform #1, there are two "HubNode" entries: "HubNode 1 : MSH8900" (IP: 192.168.101.1) and "HubNode 2 : MSH8900" (IP: 192.168.101.2). Each hub node has several child nodes: "Node 1 : MSP8001", "Node 2 : MSP8000", "Node 4 : MSP8000", and "Node 5 : MSP8020". There is also a "Power Supply" entry for each hub node, with "Power Supply 2" under HubNode 1 and "Power Supply 1" under HubNode 2. A "PSU" entry is also listed under Platform #1. On the right, a main panel displays "HubNode 1 : MSH8900" and "HubNode 2 : MSH8900". Below this, a "General Information" section shows "Name: Server 1" and "Board Status: Active, M4". A "Network Interfaces MAC : 00:a0:a5:7e:fb:de" section contains a table with columns "Source", "IP", "Netmask", and "Gateway". The "Source" dropdown is set to "DHCP", and the IP field is "0.0.0.0". The "Netmask" and "Gateway" fields are empty. At the bottom of this section are "SAVE" and "CONFIGURATION PAGE" buttons. A "Remote Access" section at the bottom contains a "KVM" button.

5.7. Server details: MSP8020

The figure below shows server details for the MSP8020 and has the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Remote access password. Refer to 5.1.9.
- ▶ Network interfaces. Refer to 5.1.4.
- ▶ Power commands. Refer to 5.1.6.
- ▶ Tools. Refer to 5.1.16.

Figure 28: Server details MSP8020

The screenshot shows the 'Components' section of the SYMKLOUD System Monitor. On the left, a tree view lists components under 'Multi-Platform': Platform #1 (HubNode 1, HubNode 2), Node 1-5, Server 1-2, and PSU. A checkmark is next to HubNode 1. In the center, two hub nodes are shown: HubNode 1 : MSH8900 containing Node 1 : MSP8001, Node 2 : MSP8000, Node 4 : MSP8000, and Node 5 : MSP8020; and HubNode 2 : MSH8900 containing Power Supply 1 and Power Supply 2. Below the hub nodes, sections for 'General Information' (Name: Server 1, Board Status: Active, M4) and 'KVM password' (Password: Kc1B0l4, SAVE button) are displayed. At the bottom, a table for 'Network Interfaces MAC : 00:a0:a5:80:30:30' shows Source (Static), IP (0.0.0.0), Netmask (0), and Gateway (0.0.0.0).

5.7.1. Network interfaces

Figure 29: Network interfaces

The screenshot shows the 'Network Interfaces MAC : 00:a0:a5:80:30:30' configuration page. It features a table with columns for Source, IP, Netmask, and Gateway. The Source is set to Static, IP is 0.0.0.0, Netmask is 0, and Gateway is 0.0.0.0. Below the table are three buttons: SAVE, PROVISION, and KVM.

For this board model, KVM access must be configured before use. This is a one-time configuration that will retain the settings between reboots.

Configuration cannot survive a loss of power to the board. If the node is extracted or the platform loses power, you will have to reconfigure.

You can configure the source in the following modes.

DHCP:

If you choose DHCP, the other parameters do not need to be set. If they are, they will be saved but not have any effect on the solution. Before using this option, you should go into the switch web interface and turn on "DHCP snooping". This will create a table of MAC addresses and the associated IPs assigned by DHCP. The MAC address of the server will be added to this interface. This will make it easier to know which IP was assigned by DHCP in the snooping table of the switch.

If you choose DHCP and use a MSP8910 switch, you can also enable snooping and show the snooping binding.

To enable snooping, use the following commands in the API:

```
#ip dhcp snooping
#ip dhcp snooping vlan 1


---


NOTICE Vlan default is 1. Use custom vlan if applicable.


---


#ip dhcp snooping database write-delay 15
#no ip dhcp snooping verify mac-address
#interface 1/0/1


---


NOTICE <unit>/<port>/<interface>
unit is the switch ID where the uplink to DHCP server is connected
You can also use "#show switch" to view all switch IDs in stack.
port is always "0"
interface can be "1", "2", "3" or "4" and corresponds to the SFP uplink on the front panel)
```

```
#ip dhcp snooping trust
```

NOTICE You must enable snooping trust on the interface to which the DHCP server is connected. If you do not, the DHCP traffic will be blocked on that port.

```
#end
```

To **show snooping binding**, use the following commands in the API:

```
#show ip dhcp snooping binding
```

This returns:

```
Total number of bindings: 1
Total number of Tentative bindings: 0
MAC Address      IP Address VLAN    Interface     Type Lease(Secs)
-----
00:A0:A5:82:0F:4D  10.0.113.113 4093    10/0/33 DYNAMIC      43055
```

Static:

In static mode, all the parameters you enter as IP addresses, netmasks (CIDR notation) and gateway addresses will be applied to the KVM.

For both solutions, you must press the "Save" button for any changes to affect provisioning. Once you have saved all values, click on the "Provision" button. This will apply the KVM settings and reset the server's payload.

Before accessing the KVM with the "Remote Access" button, wait 2-3 minutes to allow the server to reboot completely.

When you click "Remote Access", the password you set in 5/ Monitor will be set as the password for the AMT. The Java applet will be launched, giving you the remote session on the server.


5.8. PSU details

The figure below shows PSU details and has the following sections:

- ▶ Platform graphical representation. Refer to 5.1.5.
- ▶ General information. Refer to 5.1.3.
- ▶ Power consumption graph. Refer to 5.1.7.
- ▶ Sensor values. Refer to 5.1.11.
- ▶ Reset peak/average. Refer to 5.1.10.
- ▶ Tools. Refer to 5.1.16.

Figure 30: PSU details

Components

Tools ▾


6/ WEB CLI

The Symkloud System monitor includes a WEB CLI, a web-based wrapper for Serial-over-LAN (SoL) connections to node payloads. The WEB CLI requires IP access to the ShMC and target BMC(s). The WEB CLI gives access to the following components:

- ▶ Shelf Manager (and other ShMC/BMCs via the ipmitool> set "targetaddr" command)
- ▶ Switch CLI
- ▶ Node Payload OS

6.1. Connecting to the WEB CLI

To access the WEB CLI, enter the following URL in your browser:

`http://<ShMC_IP>/shell/`

NOTICE

You can also connect to a HubNode for sending CLI commands using the Console Access section of the System Monitor Dashboard page. Refer to 3.2.

6.2. Login

Use the following credentials to access the WEB CLI:

- ▶ Username: **admin** / Password: **admin**. This logs into the ipmitool> shell of the ShMC at <ShMC_IP> ("Active" ShMC if the SharedIP is used)
- ▶ Username: **console** / Password: **admin**. This provides a series of prompts to connect to the switches or nodes' payload OS

After login, the following message is displayed:

```
[SOL Session operational. Use "~?" for help]
Press [space] to continue.
```

Additional login credentials may be required once connected to switches or nodes' payload OS.

NOTICE

Only one session can be open at a time for each payload. It is recommended to close an existing session before opening a new one. Opening an additional session to the same payload will cause any existing sessions (SoL via ipmitool-over-LAN or WEB CLI) to be disconnected. No error message will be generated. The browser of the disconnected session will present the login-prompt to begin launching a new session.

7/ System Event Log (SEL)

This section allows viewing the System Event Log (SEL) of each platform.

Figure 31: System event log

Platform #1							
Date Time	Event ID	Node ID	Sensor #	Sensor Name	Sensor Type	Event Data	Event Description Text
7/14/2016 10:02:28 AM	1455	Active ShMC	41	N/A	Power Supply	0x01ffff	Failure detected
7/14/2016 10:02:22 AM	1454	Active ShMC	42	PSU2:Status Ext	Power Supply	0x810800	Failure detected
7/14/2016 10:02:22 AM	1453	Active ShMC	41	N/A	Power Supply	0xa12000	Failure detected
7/14/2016 9:29:37 AM	1452	Active ShMC	41	N/A	Power Supply	0x01ffff	Failure detected
7/14/2016 9:29:30 AM	1451	Active ShMC	42	PSU2:Status Ext	Power Supply	0x810800	Failure detected
7/14/2016 9:29:30 AM	1450	Active ShMC	41	N/A	Power Supply	0xa12000	Failure detected
7/14/2016 9:26:35 AM	1449	Active ShMC	41	N/A	Power Supply	0x01ffff	Failure detected

The System Event Log (SEL) contains one entry for each event generated by the sensors from all the nodes, PSUs and ShMCs present in the system.

You can use the SEL to:

- ▶ analyze a failure
- ▶ view if there were any activities at a given date and time (node activations, temperature events, etc.)

System Monitor automatically reads the IPMI SEL and displays the events in a list (most recent events are shown first).

At system start-up, it may take up to 15 minutes for System Monitor to read and display all events gathered from the system.

7.1. Viewing the SEL

Use the "Events per page" drop-down list to select how many events you want to see per page.

The list contains the following information:

- ▶ **Date Time:** Time at which the event occurred
- ▶ **Event ID:** ID associated with the event
- ▶ **Node ID:** Node holding the sensor that generated the event
- ▶ **Sensor #:** Sensor number
- ▶ **Sensor Name:** Sensor name
- ▶ **Sensor Type:** Sensor type as defined in the IPMI specification (or OEM defined)
- ▶ **Event Data:** Extra information from the event. This information can be used if in-depth analysis is required

- ▶ **Event Description Text:** Translation of the event and its data to text (when possible)

To export the SEL to a CSV file, select "Tools" and then "Download system event log". Save the file. You can then open it in another program (such as Excel) for further analysis.

Use the **Events per page** drop-down field to configure how many events you want to see displayed per page.

7.2. Exporting the events to a CSV file

You can export the SEL content to a CSV file.

To export the SEL to a CSV file, select "Tools" and then "Download system event log". Save the file. You can then open it in another program such as Excel for further analysis.

8/ OneClick upgrade

Use the One-Click Upgrade function to upgrade the firmware of one or more SYMKLOUD components.

The OneClick Upgrade function contains:

- ▶ Advanced settings
- ▶ Bundle settings
- ▶ Launching an upgrade
- ▶ Upgrade status

Figure 32: OneClick upgrade

[Dashboard](#) > [OneClick Upgrade](#)

OneClick Upgrade

Use this tool to upgrade the components in your multi-platform.
Specify the components to upgrade in the [advanced settings](#).

[View Advanced Settings](#) ▾

Bundle file associated with this multi-platform group:

The bundle must be a zipped file containing an XML descriptor file as well as multiple HPM upgrade files for each model that needs to be upgraded.
Specify the bundle to use in the [bundle settings](#).

[View Bundle Settings](#) ▾

By default, no downgrades will be done and up-to-date nodes will not be updated.
To upgrade regardless of installed versions click this option :

Force Upgrade

START UPGRADE ▶ **RESET**

Current Update Status

+ Multi-Platform Update

 Completed

8.1. Upgrade sequence

When launching an upgrade, the upgrade sequence is as follows:

1. Upgrade the standby HubNode
2. Upgrade the active HubNode
3. Upgrade all nodes simultaneously

8.2. Advanced settings

Figure 33: Advanced settings

Specify the components to upgrade in the [advanced settings](#).

[View Advanced Settings](#) ▾

Please select which components to upgrade:

Upgrade specific platform or upgrade a specific component

All components for the selected platform(s) will be upgraded.

Only this component will be upgraded.

Complete Multi-Platform

Select component...

Choose a model to upgrade

Only components of that model will be upgraded.

All Models

Use the Advanced Settings option to select which component(s) to upgrade. By default, this page will upgrade all components of the platform. If you come to this page after clicking on the "Upgrade Software" link on a component or

sub-component page, settings in this section will already be selected. The upgrade will target only the selected component.

Use the three drop-down menus to configure the different types of upgrades:

- ▶ All platforms, specific node model: select a model in "Choose a model to upgrade"
- ▶ Specific platform all node models: select a platform in the first drop-down menu
- ▶ Specific platform, specific node model: select both a platform in the first drop-down and a model in "Choose a model to upgrade."
- ▶ Specific platform, specific component: select both a platform and a component in the second drop-down. The model corresponding to that component will be selected automatically.

8.3. Bundle settings

Figure 34: Change bundle

The bundle must be a zipped file containing an XML descriptor file as well as multiple HPM upgrade files for each model that needs to be upgraded.
Specify the bundle to use in the [bundle settings](#).

[View Bundle Settings ▾](#)




When uploading a bundle file to a SYMKLOUD, it is automatically used by all the upgrades for that platform. To associate a new bundle to the system, use the "change bundle" function.

8.4. Launching an upgrade

Figure 35: Start upgrade

By default, no downgrades will be done and up-to-date nodes will not be updated.
To upgrade regardless of installed versions click this option :



By default, the upgrade will only apply to components with one version incremented. If the versions of the component are already up-to-date with the versions in the bundle, or if the versions in the bundle are lower than the versions on the component, the upgrade will not be performed for these components.

If you wish to force the upgrade of the components regardless of their versions, you must check the "Force Upgrade" box.

Once all the settings are set to the appropriate values, click "Start Upgrade" to launch the upgrade.

8.5. Upgrade status

The upgrade status displays the last upgrade status or the current upgrade status while an upgrade is in progress. The upgrade status has multiple levels of details that can be selected.

Figure 36: Upgrade status

8.5.1. Platform level

When the first level is expanded, one entry will be shown for each platform being upgraded. This level will display information about the component being upgraded for that platform and its model. This level's progress bar will indicate the completion of the components versus the total number of components being upgraded in this platform.

8.5.2. Component level

This level has one entry per HubNode/Node being upgraded. It will also display details about the action in progress for each component being upgraded. The progress bar at this level varies depending on the action currently executed. The state of the upgrade will also change at the right-hand side. Below are the different final states that can result from an upgrade:

- ▶ Completed
- ▶ Skipped
- ▶ Failed

9/ Remote access

This section groups the remote access features of all components in a condensed view with filtering enabled. This makes it easier to start multiple sessions targeting different components.

Figure 37: Remote access

Remote Access

The screenshot shows the 'Remote Access' section of the SYMKLOUD System Monitor. At the top right, there is a dropdown menu labeled 'Connected Components: All components'. Below this, a tree view displays the following hierarchy:

- Platform #1
 - + HubNode 1 MSH8900 192.168.101.1
 - + HubNode 2 MSH8900 192.168.101.2
 - + Node 1 MSP8001 192.168.101.11
 - + Node 2 MSP8000 192.168.101.12
 - + Node 4 MSP8000 192.168.101.14
 - Node 5 MSP8020 192.168.101.15
- Server 1 0.0.0.0
- Server 2 0.0.0.0

At the bottom right, there are two sets of buttons for each server:

- Server 1: WEB CLI (with icon), KVM (disabled)
- Server 2: WEB CLI (with icon), KVM (disabled)

10/ Network configuration

This page presents an overview of the configuration of all management interfaces.

If ShMCs and BMCs do not remain on the same VLAN and subnet at all times, undesired operations may occur. This includes, but is not limited to:

NOTICE

- ▶ Interruption of redundancy, and;
- ▶ Interruption of monitoring and management functions such as Virtual-serial (WebCLI), Firmware upgrades.

Figure 38: Network configuration

Components

The screenshot shows the SYMKLOUD System Monitor interface with two main sections: "Multi-Platform" and "Platform #1".

Multi-Platform: Shows "Platform #1" selected. A green checkmark icon is present.

Platform #1:

- System Monitor Shared IP:** A form with fields for "Base IP" and "Netmask", both currently empty. A "SAVE" button is at the bottom.
- IPMI Over Lan Configuration:** A table for configuring IP settings for nodes and hubs. It includes a header row and four data rows. The table has columns for Hub/Node, Source, Base IP, Netmask, Gateway, and VLAN. All nodes and hubs are set to "Auto" for Source, with their respective IP addresses (192.168.101.1, 192.168.101.2, 192.168.101.11, 192.168.101.12) listed under Base IP. Netmask is 255.255.255.0, Gateway is 0.0.0.0, and VLAN is 4093 for all entries.

10.1. System monitor shared IP

The System Monitor's shared IP is an address used to access the "Active" HubNode's System Monitor for the selected platform. This IP address is shared between both HubNodes (the "active" and "standby") but only the active ShMC will respond at any moment. Only static IP is supported for the Base IP and netmask. The IP address will be activated in the same VLAN and using the same gateway as that assigned to the HubNodes in the "IPMI over LAN" section.



The System Monitor's Shared IP only provides access to the Web Interface, API and SNMP calls. For ipmitool-over-LAN commands, you must use the "Active" ShMC's IP address.

10.2. IPMI Over LAN configuration



If ShMCs and BMC are not maintained on the same VLAN and subnet at all times, undesired operations may occur. This includes, but is not limited to: interruption of redundancy; interruption of monitoring and management functions, such as Virtual-serial (WebCLI); Firmware upgrades; etc.

Intelligent Platform Management Interface (IPMI) Over LAN (IOL) can be used to communicate with all node BMCs in a platform. IOL can be used to access the System Monitor as well as IPMI functionalities. You can configure the IOL settings for all nodes and HubNodes to "Manual" or "DHCP". When "Manual" is selected, the "Source" is automatically set to "Static". "Base IP", "Netmask", "Gateway" and "VLAN" must be configured for all HubNodes/nodes. When "DHCP" is selected, the "Source" is automatically set to "DHCP" but "VLAN" must be configured for all HubNodes/nodes.

11/Settings

11.1. Tech view

Users with the "technician" role can only change their password in this section.

Figure 39: General settings for a technician

General Settings

The screenshot shows a user interface for changing a password. On the left, there is a sidebar with a 'My Profile' section containing a 'Change Password' button. The main area is titled 'Change Password' and contains two input fields: 'New password:' and 'Confirm new password:', both with placeholder text. Below these fields is a horizontal line and a 'CHANGE PASSWORD' button at the bottom.

11.2. Admin view

- ▶ Users with the "administrator" role can change their password and have access to the "Administration" tools:
- ▶ Interface preferences
- ▶ User management
- ▶ Security

Figure 40: General settings for an administrator

General Settings

My Profile

Change Password >

Administration

Interface Preferences >

User Management >

Security >

Change Password

New password :

Confirm new password :

CHANGE PASSWORD

Interface Preferences

Header Logo :



PNG, JPG or GIF files only. Must have a height of 72px, a maximum width of 380px and a maximum size of 100 kB.

UPLOAD IMAGE FILE

Favicon :



ICO files only. Must have a maximum size of 100 kB.

UPLOAD IMAGE FILE

Company Name :

Primary Color :

Light Primary Color :

Secondary Color :

Light Secondary Color :

Lighter Secondary Color :

SAVE CHANGES **DEFAULT**

User Management

User	Role	Actions	
admin	Administrator		
smmgnt	IPMI	Modify	Delete

CREATE NEW USER

Security

Enable HTTPS

SELECT CERTIFICATE FILE

SELECT PRIVATE KEY FILE

Enable Strict SSL Validation

SELECT CA CERTIFICATE FILE

APPLY

11.2.1. Change password

Users with the "administrator" role can change their own password.

Figure 41: Change password

General Settings

The screenshot shows the 'General Settings' section of the SYMKLOUD System Monitor. On the left, there's a sidebar with 'My Profile' and 'Administration' sections. Under 'My Profile', 'Change Password' is selected. Under 'Administration', there are links for 'Interface Preferences', 'User Management', and 'Security'. The main area is titled 'Change Password' and contains two input fields: 'New password:' and 'Confirm new password:', both with placeholder text. Below these fields is a large 'CHANGE PASSWORD' button.

11.2.2. Interface preferences

This section provides options for customizing the branding of the web application. These options allow you to change the main logo, the browser icon and the company name used in the browser page title. Most of the colors used in the application can also be customized here.

Use the "Default" button to reset the colors to the well-coordinated colors shown below. This allows you to experiment with the colors without having to take note of the original settings. Once you press "Default", you must click on "Save Changes" to apply the color rollback.

Figure 42: Interface preferences

Interface Preferences

Header Logo :



PNG, JPG or GIF files only. Must have a height of 72px, a maximum width of 380px and a maximum size of 100 kB.

UPLOAD IMAGE FILE

Favicon :



ICO files only. Must have a maximum size of 100 kB.

UPLOAD IMAGE FILE

Company Name :

Primary Color :

Light Primary Color :

Secondary Color :

Light Secondary Color :

Lighter Secondary Color :

SAVE CHANGES **DEFAULT**

11.2.3. User management

An administrator also has access to the "User management" section, which lists the system's current users.

All users can be deleted or modified except the user with the name "admin" and the user with the role "IPMI".

The user with the name "admin" and the user with the role "IPMI" cannot be deleted. They also cannot be renamed or be assigned another role. Only their passwords can be modified. This ensures the presence of at least one user with the "admin" and the "IPMI" roles. Other users with the "admin" role can be modified.

There can only be one user with the "IPMI" role and its name is predefined and fixed as "smmgnt". It can be used for IOL access to the system.

Users with the "admin" role can change the name, password and role of other users.

Users with the "technician" role can only change their password, not their name or their role.

Figure 43: User management

User Management		
User	Role	Actions
admin	Administrator	
smmgmt	IPMI	Modify Delete
CREATE NEW USER		

Use the "Create New User" button to create a new user. The pop-up window is shown below.

Figure 44: Creating new user

Create new user

×

User: (alpha-numeric characters only)

Password: (excluding ", , \)


Confirm password :

Role :

[CREATE USER](#)

Each user name must be unique. User names must only contain letters and numbers. The password does not allow the following characters: "", "", and "\". An error message will be displayed if the name being created or modified already exists.

Figure 45: Error message: user already exists



11.2.4. Security

This section allows enabling secure communication using the HTTPS protocol.

Figure 46: Security



11.2.5. Certificate and private key

An administrator can optionally supply his own certificate and private key using the "Select certificate file" and "Select private key file" buttons. By default, a self-signed certificate is used in the secured communication.

11.2.6. Strict SSL Validation and CA Certificate

When enabling "Strict SSL Validation", exchanges between SYMKLOUD platforms will use the supplied CA certificate for validation that the remote platform has a valid certificate (Not yet available in the current release). The CA certificate can be selected with the "Select CA certificate file" button.

12/ Help

12.1. API documentation

This link will open a new browser tab with a one page documentation of every available call in the API.

Figure 47: API documentation example

AUTHENTICATION

AUTH

GET / POST

Description: The API 3.0 uses a [Basic http Authentication](#) on nearly all request. The Auth call is used to authenticate the user and generate a temporary token that expires after 30 minutes of inactivity. The token is used as the password for every subsequent API requests that require Authentication.

Call: /v3/Auth

Return:

Success: JSON object containing attributes:

- status
- code
- token : The token to use for other request that need authentication
- roleKey : The role key of the authenticated user
- roleText : The role text for the authenticated user.

Possible errors:

```
{"status":"Failure", "code": 23, "message": "Invalid password for user"}  
{"status":"Failure", "code": 29, "message": "Basic HTTP Authentication required"}
```

Example cURL command :

```
curl -u <user>:<password> http://<platformIP>:9090/v3/Auth
```


12.2. About

Version information about the web and core applications.

NOTICE

The version displayed in the next figure is an example only. It does not reflect the actual system version.

Figure 48: About window





About Kontron

Kontron, a global leader in embedded computing technology and trusted advisor in IoT, works closely with its customers, allowing them to focus on their core competencies by offering a complete and integrated portfolio of hardware, software and services designed to help them make the most of their applications.

With a significant percentage of employees in research and development, Kontron creates many of the standards that drive the world's embedded computing platforms; bringing to life numerous technologies and applications that touch millions of lives. The result is an accelerated time-to-market, reduced total-cost-of-ownership, product longevity and the best possible overall application with leading-edge, highest reliability embedded technology

Kontron is a listed company. Its shares are traded in the Prime Standard segment of the Frankfurt Stock Exchange and on other exchanges under the symbol "KBC". For more information, please visit: <http://www.kontron.com/>



CORPORATE OFFICES

EUROPE, MIDDLE EAST & AFRICA

Lise-Meitner-Str. 3-5
86156 Augsburg
Germany
Tel.: +49 821 4086-0
Fax: +49 821 4086-111
info@kontron.com

NORTH AMERICA

14118 Stowe Drive
Poway, CA 92064-7147
USA
Tel.: +1 888 294 4558
Fax: +1 858 677 0898
info@us.kontron.com

ASIA PACIFIC

1-2F, 10 Building, No. 8 Liangshuihe 2nd Street,
Economical & Technological Development Zone,
Beijing, 100176, P.R. China
Tel.: +86 10 63751188
Fax: +86 10 83682438
info@kontron.cn