



kontron

» Kontron User's Guide «



MSP8000/8001
Document Revision 1.0

Revision History

Revision	Brief description of changes	Date of issue
1.0	First release	July 2014

Customer Service

Contact Information:

Kontron Canada, Inc.
 4555 Ambroise-Lafortune
 Boisbriand, Quebec, Canada
 J7H 0A4
 Tel: 450-437-5682
 1-800-354-4223
 Fax: 450-437-8053
 E-mail: support@ca.kontron.com

Kontron Modular Computer GMBH
 Sudetenstrasse 7
 87600 Kaufbeuren
 Germany
 +49 (0) 8341 803 333
 +49 (0) 8341 803 339
 E-mail: support@kontron.com

Visit our site at: www.kontron.com

Copyright © 2013 Kontron America Inc.

All rights reserved. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), without the express written permission from Kontron.

Customer Comments

If you have any difficulties using this user's guide, discover an error, or just want to provide some feedback, please send a message to Kontron. Detail any errors you find. We will correct the errors or problems as soon as possible and post the revised user's guide on our website. Thank you.

Acronyms

API	Application Programming Interface
BMC	Base Management Controller
BP	Backplane
CLI	Command-Line Interface
DMI	Desktop Management Interface
ECC	Error Checking and Correction
HPM	PICMG Hardware Platform Management specification family
IOL	IPMI-Over-LAN
IPMI	Intelligent Platform Management Interface
KCS	Keyboard Controller Style
KVM	Keyboard Video Mouse
NCSI	Network Communications Services Interface
PCIe	PCI-Express
RAM	Random Access Memory
ShMC	Shelf Management Controller
SMWI	System Monitor Web Interface
SOL	Serial Over LAN
SSD	Solid-State Drive
VLP	Very Low Profile

Table of Contents

1	Product Description	7
1.1	Product Overview	7
1.2	Block Diagram	9
1.3	PCI Mapping.....	10
1.4	Node Key Components	11
1.5	Node Features	11
1.7	Network Interfacing	13
1.8	Management Interfacing	13
2	Extracting and Inserting a Node Module	16
2.1	Extracting a Node Module.....	16
2.2	Inserting a Node Module	16
2.3	System Behavior upon Hot Swap.....	16
3	Software Configurations and Conventions.....	17
4	Configuring Node Modules	18
4.1	Node Reset	18
4.2	Boot Order	18
4.3	Boot from Virtual Media.....	19
4.4	OS Installation	19
5	Performing Updates	20
5.1	Processor Node Update	20
5.2	One Click Upgrade to Update all Nodes.....	20

List of Figures

Figure 1: SYMKLOUD layers	7
Figure 2: MSP8000 or MSP8001 in rear of chassis	8
Figure 3: MSP8000 and MSP8001 block diagram	9
Figure 4: MSP8000 and MSP8001 LEDs and buttons	12
Figure 5: Diagram of interface paths with a management networking connection.....	14
Figure 6: Diagram of interface paths with a serial console connection	15
Figure 7: Processor node module safety lock location.....	16

List of Tables

Table 1: PCI Mapping	10
Table 2: Node key components	11
Table 3: Node features	11
Table 4: LED status description and button behavior.....	12
Table 5: Default usernames and passwords of management interfaces	15

Electrostatic Discharge

CAUTION! The MSP8000 and MSP8001 nodes are sensitive to electrostatic discharge (ESD). Users must observe the appropriate precautions when handling ESD-sensitive devices.

Limited Warranty

Kontron grants the original purchaser of Kontron's products a TWO YEAR LIMITED HARDWARE WARRANTY as described in the following. However, no other warranties that may be granted or implied by anyone on behalf of Kontron are valid unless the consumer has the express written consent of Kontron.

Kontron warrants their own products, excluding software, to be free from manufacturing and material defects for a period of 24 consecutive months from the date of purchase. This warranty is not transferable nor extendible to cover any other users or long-term storage of the product. It does not cover products which have been modified, altered or repaired by any other party than Kontron or their authorized agents. Furthermore, any product which has been, or is suspected of being damaged as a result of negligence, improper use, incorrect handling, servicing or maintenance, or which has been damaged as a result of excessive current/voltage or temperature, or which has had its serial number(s), any other markings or parts thereof altered, defaced or removed will also be excluded from this warranty.

If the customer's eligibility for warranty has not been voided, in the event of any claim, he may return the product at the earliest possible convenience to the original place of purchase, together with a copy of the original document of purchase, a full description of the application the product is used on and a description of the defect. Pack the product in such a way as to ensure safe transportation (see our safety instructions).

Kontron provides for repair or replacement of any part, assembly or sub-assembly at their own discretion, or to refund the original cost of purchase, if appropriate. In the event of repair, refunding or replacement of any part, the ownership of the removed or replaced parts reverts to Kontron, and the remaining part of the original guarantee, or any new guarantee to cover the repaired or replaced items, will be transferred to cover the new or repaired items. Any extensions to the original guarantee are considered gestures of goodwill, and will be defined in the "Repair Report" issued by Kontron with the repaired or replaced item.

Kontron will not accept liability for any further claims resulting directly or indirectly from any warranty claim, other than the above specified repair, replacement or refunding. In particular, all claims for damage to any system or process in which the product was employed, or any loss incurred as a result of the product not functioning at any given time, are excluded. The extent of Kontron liability to the customer shall not exceed the original purchase price of the item for which the claim exists.

Kontron issues no warranty or representation, either explicit or implicit, with respect to its products reliability, fitness, quality, marketability or ability to fulfill any particular application or purpose. As a result, the products are sold "as is," and the responsibility to ensure their suitability for any given task remains that of the purchaser. In no event will Kontron be liable for direct, indirect or consequential damages resulting from the use of our hardware or software products, or documentation, even if Kontron were advised of the possibility of such claims prior to the purchase of the product or during any period since the date of its purchase.

Please remember that no Kontron employee, dealer or agent is authorized to make any modification or addition to the above specified terms, either verbally or in any other form, written or electronically transmitted, without the company's consent.


1 Product Description

1.1 Product Overview

The MSP8000 and MSP8001 are processor nodes for the SYMKLOUD MS2900 platform. Nine nodes can be installed in each MS2900. When used with the MSH8900 hub, the MSP8000 node supports two 1GbE ports and the MSP8001 node supports four 1GbE ports with the exception of nodes 7 and 9 that support three 1GbE ports and one 10GbE port.


An OS must be loaded on the processor nodes for the system to be operational.

Figure 1: SYMKLOUD layers



CP0035

Figure 2: MSP8000 or MSP8001 in rear of chassis




CP0037

For information on other SYMKLOUD MS2900 components, refer to the specific component's user manual.

To ensure you have the latest document version or to consult other SYMKLOUD documents, visit the Kontron portal at <http://cbu.kontron.ca/>.

1.2 Block Diagram

Figure 3: MSP8000 and MSP8001 block diagram



For a block diagram of the entire MS2900 system, refer to the *SYMKLOUD MS2900 Platform User's Guide*.

1.3 PCI Mapping

Table 1: PCI Mapping

Bus:Device: Function	Device ID	Component	Description	Note
CPU				
00:00.0	0158	Host bridge	Intel Corporation Ivy Bridge DRAM Controller (rev. 09)	Intel E3-1265LV2 processor
00:01.0	0151	PCI bridge	Intel Corporation 3rd Gen Core processor PCI Express Root Port (rev. 09)	MSP8001 only
Chipset				
00:14.0	1e31	USB controller	Intel Corporation 7 Series Chipset Family USB xHCI Host Controller (rev. 04)	Intel C216 chipset
00:16.0	1e3a	Communication controller	Intel Corporation 7 Series Chipset Family MEI Controller No. 1 (rev. 04)	
00:1c.0	1e10	PCI bridge	Intel Corporation 7 Series Chipset Family PCI Express Root Port 1 (rev. c4)	
00:1c.1	1e12	PCI bridge	Intel Corporation 7 Series Chipset Family PCI Express Root Port 2 (rev. c4)	
00:1c.2	1e14	PCI bridge	Intel Corporation 7 Series Chipset Family PCI Express Root Port 3 (rev. c4)	
00:1d.0	1e26	USB controller	Intel Corporation 7 Series Chipset Family USB Enhanced Host Controller No. 1 (rev. 04)	
00:1e.0	244e	PCI bridge	Intel Corporation 82801 PCI Bridge (rev. a4)	
00:1f.0	1e53	ISA bridge	Intel Corporation Panther Point LPC Controller (rev. 04)	
00:1f.2	1e02	SATA controller	Intel Corporation 7 Series Chipset Family 6-port SATA AHCI Controller (rev. 04)	
00:1f.3	1e22	SMBus	Intel Corporation 7 Series Chipset Family SMBus Controller (rev. 04)	
Network devices				
02:00.0	1537	Ethernet controller	Intel Corporation (rev. 03)	Intel I210-IS 1Gb Ethernet to Hub 1
03:00.0	1537	Ethernet controller	Intel Corporation (rev. 03)	Intel I210-IS 1Gb Ethernet to Hub 2
BMC				
04:00.0	0013	PCI bridge	Renesas Technology Corp. SH7757 PCIe Switch [PS]	Renesas SH7757 BMC
05:00.0	0013	PCI bridge	Renesas Technology Corp. SH7757 PCIe Switch [PS]	
05:01.0	0013	PCI bridge	Renesas Technology Corp. SH7757 PCIe Switch [PS]	
07:00.0	0012	PCI bridge	Renesas Technology Corp. SH7757 PCIe-PCI Bridge [PPB]	
08:00.0	0534	VGA compatible controller	Matrox Electronics Systems Ltd. G200eR2	
Network devices				
09:00.0	10f8	Ethernet controller	Intel Corporation 82599EB 10 Gigabit Dual Port Backplane Connection (rev. 01)	Intel 82599EB 1Gb/10Gb to hub 1, MSP8001 only
09:00.1	10f8	Ethernet controller	Intel Corporation 82599EB 10 Gigabit Dual Port Backplane Connection (rev. 01)	Intel 82599EB 1Gb/10Gb to hub 2, MSP8001 only

1.4 Node Key Components

Table 2: Node key components

Component*	Description
CPU	1 Intel® Xeon® E3-1220L v2, 3 MB cache, 2.3 GHz, 17 W, dual-core OR 1 Intel® Xeon® E3-1265L v2, 8 MB cache, 2.5 GHz, 45 W, quad-core
Chipset	1 Intel® C216 PCH
System memory	4 DIMM slots for up to 32 GB DDR3, supports ULP unbuffered 1.5V DDR3 with ECC, up to 1600 MHz
Network connections	2 Intel® I210-IS 1GbE controllers 1 Intel® 82599EB dual 10GbE controller (MSP8001 only)
Storage	1 or 2 2.5-inch SATA SSD/HDD depending on CPU/heatsink option
I/O devices	2 6-Gbps SATA ports 1 serial port through backplane and MSH8900 hub 1 serial port through SOL via the integrated BMC 1 KVM (Keyboard, Video, Mouse) accessible over LAN 1 USB storage via virtual media over LAN 1 optional OEM mezzanine (for PCIe x8 Gen 2)
BIOS	8 MB SPI AMI UEFI BIOS

* Some of the components are optional.

Refer to the Intel website ark.intel.com for more information on Intel components.

1.5 Node Features


Table 3: Node features

Feature	Description
Remote management	IPMI 2.0 IOL SOL KVM/virtual media Remote firmware update Comprehensive sensor network and event monitoring Refer to the <i>MSP8000/8001 Sensor List</i> for a list of sensors
Validated OS	Ubuntu Server, 64-bit, long-term support release 12.04 Red Hat Enterprise Linux Server, 64-bit, release 6.3 SUSE Linux Enterprise Server 11, 64-bit, SP2 Windows Server 2008 R2, 64-bit, SP1
Hot swap	For a list of current validated OS, refer to the product's THOL. Supported
Power consumption	Refer to the <i>MSH8900 User's Guide</i> for information on system behavior upon hot swap May vary depending on SSD/HDD model MSP8000: 43 W max (E3-1220L v2) 67 W max (E3-1265L v2) MSP8001: 73 W max (E3-1265L v2)
Power management	The maximums are typical. Tests were conducted with 32 GB of 1600 MHz DDR3 and 2 SSDs, running a combination of CPU, memory, storage and network stress test applications. Support for suspend-to-RAM and suspend-to-disk

For a complete list of system features, refer to the *SYMKLOUD MS2900 Platform User's Guide*.

1.6 Node Module LEDs and Buttons

Figure 4: MSP8000 and MSP8001 LEDs and buttons



CP0036

Table 4: LED status description and button behavior

MSP8000/8001			
State	ID (blue)	Power (green)	Status (amber)
Identify command in progress	Blinking ¹	Not affected	Not affected
Payload power ON	OFF	ON	ON: not healthy OFF: healthy
Payload power OFF or suspend-to-disk	ON	OFF	ON: not healthy OFF: healthy
Suspend-to-RAM	ON	Blinking ²	ON: not healthy OFF: healthy

¹ Fast blink, 1 Hz, 50%² Slow blink, 0.5 Hz, 20%

Power button		
State	Short press	Long press
Power OFF OR Suspend-to-RAM	Powers the node	Nothing happens
Power ON	Performs a clean shutdown of the node or enables suspend-to-RAM (OS configuration dependant)	Turns node off immediately

1.7 Network Interfacing

The MSP8001 node supports four 1GbE ports when installed in chassis slots 1-6 or 8. However, when installed in chassis slots 7 or 9, it supports three 1GbE ports and one 10GbE port.

In slot 7, the 10GbE link is on the F1 port and goes to hub 1. In slot 9, the 10GbE link is on the F2 port and goes to hub 2. For a complete port mapping and network topology of the system, refer to the *MSH8900 User's Guide*.

1.8 Management Interfacing

Two types of connections can be established with node components: a management networking connection or a serial console connection.

The SYMKLOUD platform comes with a System Monitor Web Interface (SMWI). The SMWI can be used to update node components.


Refer to the *SYMKLOUD MS2900 Platform Quick Start Guide* for an overview of the SMWI and for information on how to access it as well as for the locations of the management and console ports.

The IP address of the component you want to connect to might be required when using certain paths. For a list of the default IP addresses of components, refer to the *SYMKLOUD MS2900 Platform Quick Start Guide*.

The MSP8000 and MSP8001 nodes have a KVM functionality that gives users remote access to the CPU engine. The remote console is the redirected screen, keyboard and mouse of the remote host system. Through media redirection, this functionality allows users to mount a device, e.g. a USB drive or ISO image, as a remote device to the CPU engine. Once mounted, the device appears as a local device.

Figure 5 and Figure 6 show the steps required to access the system's various interfaces.

Figure 5: Diagram of interface paths with a management networking connection



CP0038B

NOTES:

- » Terminal emulator software such as PuTTY can be used.
- » The Kontron ipmitool package can be downloaded from site <http://cbu.kontron.ca/>, under Software Tools.
- » Ensure the protocol is enabled for the interface you want to access.
- » An IOL connection allows users to send ipmitool commands that will immediately be executed by the node BMC.


Example of SOL connection to the node CPU serial console (OS):

1. Connect to the management port with a cable or via a network.
2. Establish an SOL connection using ipmitool:
 - a. From a PC: ipmitool -H <node ip address> -U admin -P admin -I lanplus sol activate
 - b. From the ShMC CLI: under construction
3. The OS specific prompt is displayed, e.g. **Login**.

Example of an HTTP connection to the node KVM:

1. Connect to the management port with a cable or via a network.
2. Open a Web browser and enter the IP address of the hub to access the SMWI.
3. Click on **Node n** and then on **Create Session** under section Remote access.

Figure 6: Diagram of interface paths with a serial console connection



CP0031

The serial port communication parameters are 115200 baud, no parity, 8 data bits and backspace key set to "Ctrl-h". BIOS POST and configuration menu redirection is VT100+.

NOTE: The ASCII control code for "Ctrl-g" is 7. To type "Ctrl-gg", use the "Ctrl-g" ASCII control code 2 times in a row.

Example of a serial connection to the node CPU serial console (OS):

1. Connect a PC to the active hub's console port
2. Establish a connection using the PC terminal emulator with parameters 115200 baud, no parity, one stop bit
3. To configure the hub console port MUX, type **Ctrl-g <Node No. (1-9)>**, then **Ctrl-gg**.

Table 5: Default usernames and passwords of management interfaces

Configuration interface	Username and password
MS2900 SMWI	admin admin
ShMC CLI	admin admin
Node CPU serial console (OS)	Customer specific


2 Extracting and Inserting a Node Module

2.1 Extracting a Node Module

NOTE: Steps in blue apply only to hot swap procedures.

1. Take all necessary ESD protection measures.
2. Press the power button of the node to be extracted. (The power button should be configured in the operating system so as to perform a clean shutdown when pressed.)
3. The ID LED of the node becomes steady blue: the node is ready to be extracted.
4. To extract the node module from the slot, pull on the handle while pressing the safety lock (Figure 7) towards the left.

Figure 7: Processor node module safety lock location



CP0020

2.2 Inserting a Node Module

1. Holding the handle, insert a node module.
2. Push it in until the safety lock locks in place.
3. Press the power button of the node module that was inserted. The power LED of the processor node module becomes steady green: the node is powered on and ready to use.

2.3 System Behavior upon Hot Swap

NOTE: The system is electrically designed to support a surprise extraction. However, this type of extraction is not recommended and could affect system performance and functionalities.

When a hot-swap procedure is performed on nodes MSP8000 or MSP8001, the following systems and functionalities could be affected:

- » All nodes: Node dedicated applications could be affected.
- » Node 7 or 9: A SYMbalance connection could be lost.

3 Software Configurations and Conventions

Before you start configuring node modules, read the following list of mandatory tasks. You can refer to that list to ensure you have performed the basic tasks required for proper system operation. Note that some of these tasks can already have been done.

Mandatory tasks:

- » Booting from LAN, from virtual media or from disk onboard
- » Installing an OS

The following conventions are used in this guide:

Conventions:

- » Elements between <> in blue are variables. The value shown is an example or an instruction on what to enter. Items between () show a value range for the variable spelled out, e.g. <Switch No. (1-5)> means you must enter the switch number and that this number can be between 1 and 5.
- » The | symbol indicates a choice between two or more alternatives, e.g. x|y|z reads “x or y or z”.
- » Elements in black bold are selectable menu items or button names.
- » Elements in blue *italics* are configuration options or types.
- » The > symbol separates a series of operations required to access a specific element.
- » Refer to the *MSH8900 User's Guide* for the IPMI mapping of the system.
- » Refer to the *SYMKLOUD MS2900 Platform Quick Start Guide* for a list of default IP addresses.

Configuration command tables:

Sections 4 and 5 contain 2-column tables. The first column describes steps that can be performed in the Web-type interface(s) named in the header. The second column describes steps that can be performed in CLI-type interface(s) specified in the header. See Figure 5 and Figure 6 to find out how to access the specified Web-type or CLI-type interface.

4 Configuring Node Modules

4.1 Node Reset

To reset the CPU of a node:

SMWI, KVM, Node Web UI	Node CPU serial console, ShMC CLI, IOL remote PC
<p><i>From the SMWI</i> Under construction</p>	<p><i>From the Node CUP serial console</i> Send a break sequence</p> <p><i>From the ShMC CLI</i> ipmitool> ipmitool> set targetaddr <node ipmi address> ipmitool> power reset</p> <p><i>From an IOL remote PC</i> > ipmitool -H <node BMC ip address> -U admin -P admin power reset <i>OR</i> > ipmitool -H <ShMC ip address > -U admin -P admin -t <node ipmi address> power reset</p>
Notes	
	<p>For the node CPU serial console connection, the method is terminal emulator specific, e.g. with putty type Ctrl-break or use menu Special command and select Break.</p>

4.2 Boot Order

To choose the boot order of a processor node:

KVM	Node CPU serial console
<p>Perform a node reset (section 4.1) Press F2 when prompted to enter the bios setup menu Select the Boot tab to display the current boot order</p> <p><i>To choose the Boot Option Priority</i> Use the up or down arrow key to select a boot device Use the + or – key to move the boot device up or down Select the Save & Exit tab Select Save Changes and Reset</p>	<p>Perform a node reset (section 4.1) Press F2 when prompted to enter the bios setup menu Select the Boot tab to display the current boot order</p> <p><i>To choose the Boot Option Priority</i> Use the up or down arrow key to select a boot device Use the + or – key to move the boot device up or down Select the Save & Exit tab Select Save Changes and Reset</p>
Notes	
<p>You could boot from LAN, from virtual media or from disk on board. The default Boot Priority Order is: virtual media (if open), hard drive (if installed), Base Interface LAN, Fabric Interface LAN.</p>	

To change the boot order of a processor node temporarily:

KVM	Node CPU serial console
Perform a node reset (section 4.1) Press F7 when prompted to enter the boot menu Detected boot devices are displayed Use the up or down arrow key to select a boot device Press Enter	Perform a node reset (section 4.1) Press F7 when prompted to enter the boot menu Detected boot devices are displayed Use the up or down arrow key to select a boot device Press Enter
Notes	
You could boot from LAN, from virtual media or from disk on board.	

4.3 Boot from Virtual Media

To boot a processor node from a virtual media:

KVM	Not possible from a CLI-type interface
Select the Media tab Connect the media device and select the appropriate option Click on Close Perform a node reset (section 4.1) Set the boot priority of your media device (section 4.2)	
Notes	
The possible options are virtual floppy, virtual CD and virtual hard disk.	

4.4 OS Installation

To install an OS:

KVM	Not possible from a CLI-type interface
Boot from LAN or from virtual media (section 4.3) Select the CD/DVD option Proceed with installation	

5 Performing Updates

An HPM file provided by Kontron contains firmware updates for node components.

5.1 Processor Node Update

To update the firmware of the node BMC, BIOS and FPGA:

SMWI	Computer command prompt
Select Node n Click on tab Software Upgrade Click on Select HPM file to upload Select the HPM file from its location in your network Click on Open Click on Upload to BMC Click on Start upgrade once available	API under construction
Notes	
This operation must be done for all nodes.	

5.2 One Click Upgrade to Update all Nodes

To update the firmware of the node BMC, BIOS and FPGA of all nodes sequentially:

SMWI	Computer command prompt
Click on tab OneClick Upgrade Select All to update all nodes and the 2 ShMC <i>OR</i> Select MSP8000 to update all nodes <i>OR</i> Select MSP8001 to update all nodes Select the HPM file from its location in your network Click on Open Click on Upload to BMC Click on Start process	API under construction
Notes	
The update will be performed only on the components for which files are included in the HPM file bundle.	

CORPORATE OFFICES

Europe, Middle East & Africa

Oskar-von-Miller-Str. 1
85386 Eching / Munich
Germany
Tel.: + 49 (0) 8165 / 77 777
Fax: + 49 (0) 8165 / 77 219
info@kontron.com

North America

14118 Stowe Drive
Poway, CA 92064-7147
USA
Tel.: + 1 888 294 4558
Fax: + 1 858 677 0898
info@us.kontron.com

Asia Pacific

17 Building, Block #1, ABP.
188 Southern West 4th Ring Road
Beijing 100070, P.R.China
Tel.: + 86 10 63751188
Fax: + 86 10 83682438
info@kontron.cn